

10072728.020702




FIG. 1

20200822001




FIG. 1A
(PRIOR ART)




FIG. 2

20200228 007200




FIG. 3




FIG. 3A

2022082200T




FIG. 4

10072729.020702




FIG. 5B




FIG. 5A
(PRIOR ART)

20240208222001






FIG. 6

20200822001



10072728.020702




FIG. 8B




FIG. 8A

FIG. 10

10072728.020702




FIG. 10A

202008227002




FIG. II

10072728.020702




FIG. 12

HERE IS A WINDOWS HEADER SHOWING THE COMMAND OPTIONS BANNER AS IT APPEARS ON THE SCREEN




FIG. 13A

DARK LINES HAVE BEEN ADDED TO DEFINE A TORQUE TROUGH ARROWS INDICATE MOTION IN X&Y AXES




FIG. 13B

CURVES BELOW SHOW TORQUE PROFILE FOR X & Y AXES MOVEMENTS INDICATED ABOVE.





FIG. 13D

10072728.020702